

KONAMI



Cancel Credits

1. Insert and turn **RESET** key.
2. Insert and turn **AUDIT** key.
3. Record the current **Cancel credit Meter**.

Banknote Clearance

1. Insert and turn **AUDIT** key.
2. Open **Banknote door**.
3. Press the **gamble button** twice.
4. Select **Banknote Clearance**.
5. Press **COLLECT** and **SPIN**.